

**L58 fuse carriers 690V - 125A Accessory free**

Description	Cat ref.
Fuse carrier 1P 125A 690V L58 2M	LR701
Fuse carrier 3P 125A 690V L58 6M	LR703

LR701

**Fuse Switch Disconnectors**

Description	Cat ref.
Fuse switch disconnecter LT size 00 160A, screw terminal M8, DIN rail	LT052
Fuse switch disconnecter LT size 1 250A for mounting plate, terminal M10	LT150

LT052